



77-0010 | Wiper Instructions

Note - These wipers are only recommended for poly windshield that are hard coated or glass windshields with a metal frame (hole must be drilled in metal frame). Un-coated windshields can easily scratch with the use of this wiper.

Manual wiper installation instructions for poly hard-coated windshields

Step #1

Ensure the best location on your windshield so there will be no interference with the operation of the wiper blade or manual handle.

Step #2

Apply masking tape to both sides of the windshield and mark your mounting location.

Step #3

Using a 1/2" step style drill bit (not included), drill your mounting hole in the desired location.



Step #4

Remove the masking tape and install the wiper assembly.